## RG6 / 12 Regulator Fitting Instructions



## **Description:**

AC regulator to prevent bulb failure. For 6 volt systems - leave loop intact.

RG12 for 12 volt systems - cut loop

## NOTE:

It's recommended that the earth connections are linked together.

